

AMERICAN FURNITURE DEMOLITION & EARTHWORK

TEMPORARY SEDIMENT AND EROSION CONTROL DRAWINGS ALBUQUERQUE, BERNALILLO COUNTY, NEW MEXICO



- 1 COVER SHEET
- 2 SWPPP NOTES
- **3 GENERAL AND COA NOTES**
- **4 BEST MANAGEMENT PRACTICES**
- **5 BEST MANAGEMENT PRACTICES**
- 6 BEST MANAGEMENT PRACTICES 7 BEST MANAGEMENT PRACTICES
- 8 TEMPORARY EROSION & SEDIMENT CONTROL PLAN
- 9 FINAL STABILIZATION












www.e2rc.com | 505.867.4040



GUZMAN CONSTRUCTION
SOLUTIONS, LLC
AMERICAN FURNITURE
DEMOLITION & EARTHWORK

DESIGNED BY:
K. FETTER, P.E.
DRAWN BY:
S. FETTER

SHEET:

1- COVER

PROJECT DETAILS

NPDES ID: NMR10068E, NMR10068F

ADDRESS: 3535 MENAUL BLVD. NE, ALBUQUERQUE, NM 87107

GPS COORDINATES: 35.110390, -106.605118

PROPERTY ACREAGE: 9.8

ANTICIPATED DISTURBED ACREAGE: 5.8

MAXIMUM DISTURBED ACREAGE: 5.8

FIRST RECEIVING WATER: RIO GRANDE

WATERS WITHIN ONE MILE OF PROJECT: AMAFCA N. DIVERSION CHANNEL

IMPAIRED/TIERED WATERS: RIO GRANDE

ENDANGERED SPECIES: CRITERION A

SUPPORT ACTIVITIES: SEE SECTION 3.6 OF SWPPP NARRATIVE

SOIL TYPE: SEE NRCS SOIL REPORT PROVIDED IN SWPPP BINDER

TYPE PRE-CONSTRUCTION COVER: EXISTING BUILDING, ASPHALT PAVING

STABILIZATION MEASURES AND DEADLINES: SEE SECTION 6.0 OF SWPPP NARRATIVE

REGULATING AUTHORITY: ENVIRONMENTAL PROTECTION AGENCY (EPA)

OPERATORS

PROPERTY OWNER: VISTA ORIENTE, LTD, CO. 500 4TH ST. NW ALBUQUERQUE, NM 87102

OWNER CONTACT: JEFF JESIONOWSKI (505) 259-0991 JEFF@AMCDEVELOPMENT

GENERAL CONTRACTOR (GC): GUZMAN CONSTRUCTION SOLUTIONS, LLC 6020 INDUSTRY WAY SE ALBUQUERQUE, NM 87105

GC CONTACT: **EDDIE GONZALES** (505) 975-8149 EDDIE@GUZMANCS.COM

STORMWATER TEAM

SEE SECTION 2.0 OF THE SWPPP NARRATIVE FOR THE PROJECT'S STORMWATER TEAM, RESPONSIBILITIES AND **CONTACT INFORMATION**

SEQUENCE OF ACTIVITIES

DEMOLITION & GRADING

PHASE I: SITE PREPARATION AND PRE - CONSTRUCTION

1.PRIOR TO BEGINNING DEMOLITION AND EARTH DISTURBING ACTIVITIES, THE OPERATOR(S) WILL CLEARLY DEMARCATE THE LIMITS OF DISTURBANCE WITH STAKES, RIBBONS, CONSTRUCTION FENCING, OR OTHER APPROPRIATE METHOD. THESE DEMARCATIONS SHALL REMAIN VISIBLE FOR THE DURATION OF THE PROJECT

2.THE INITIAL EROSION CONTROL MEASURES SHALL BE INSTALLED PRIOR TO EARTH DISTURBANCE. THE INITIAL CONTROL MEASURES MAY INCLUDE BUT ARE NOT LIMITED TO:

- a. PERIMETER CONTROLS (E.G., SILT FENCE, WATTLES, CONSTRUCTION FENCE)
- b. VEHICLE TRACKING PAD IF THE SITE ENTERS/EXITS ONTO A PAVED PUBLIC ROADWAY
- c. NPDES NOTIFICATION POSTING
- d DESIGNATED STAGING AREA
- e. ANCHORED SANILETS
- f. DUMPSTERS

PHASE II: DEMOLITION ACTIVITIES

- 1.THE OPERATORS WILL MINIMIZE THE AREA DISTURBED AS MUCH AS FEASIBLY POSSIBLE.
- 2. CONSTRUCT THE STORMWATER PONDS AND DIVERSION SWALES AS SOON AS THE ASPHALT UNDERLYING THE LOCATION OF EACH POND HAS BEEN REMOVED. REFER TO THE APPROVED GRADING & DRAINAGE PLAN FOR THE POND SIZE AND LOCATION DETAILS.

3.ANY DISTURBED AREA IN WHICH CONSTRUCTION ACTIVITIES HAVE TEMPORARILY CEASED SHALL TEMPORARILY STABILIZED USING THE METHODS DESCRIBED IN SECTION 6.4 OF THE SWPPP NARRATIVE. SECTION 6.3 OF THE SWPPP NARRATIVE PROVIDES THE

4.THE LOCATION OF SOME BMPS MAY REQUIRE ALTERATION IF DRAINAGE PATTERNS CHANGE DURING CONSTRUCTION. THE OPERATORS SHALL INSTALL ADDITIONAL BMPS OR UPGRADE BMPS IF NECESSARY.

5.IF CONCRETE IS USED ONSITE AND CONCRETE TRUCKS ARE UNABLE TO WASHOUT OFFSITE. THE OPERATORS WILL PROVIDE ONE OR MORE DESIGNATED CONCRETE WASHOUT AREAS. THE CONCRETE WASHOUTS MUST BE INSTALLED PRIOR TO CONCRETE USE ONSITE AND REMOVED ONLY AFTER CONCRETE WORK IS COMPLETE.

PHASE III: STABILIZATION

- 1. IF VERTICAL CONSTRUCTION DOES NOT BEGIN WITHIN 14 DAYS OF CEASING EARTH DISTURBING ACTIVITIES, THE DISTURBED AREA WILL BE TEMPORARILY STABILIZED.
- 2. DISTURBED AREAS WILL BE TEMPORARILY STABILIZED WITH TACKIFER FOLLOWING THE COMPLETE DEMOLITION AND REMEDIATION. THE PROJECT AREA WILL NOT BE SEEDED AS THE PROPERTY OWNER EXPECTS TO START NEW CONSTRUCTION SOON AFTER. TACKIFER WILL BE APPLIED EVERY SIX MONTHS IF NEW CONSTRUCTION IS DELAYED. THE SILT FENCE WILL REMAIN IN PLACE UNTIL NEW CONSTRUCTION BEGINS
- 3. FOLLOWING REMEDIATION, MAINTAIN ALL STORMWATER CONTROLS LEADING UP TO AND DURING INSFRASTRUCTURE CONSTRUCTION
- 4. STORMWATER CONTROLS MAY ONLY BE REMOVED AFTER THE SITE MEETS THE EPA'S FINAL STABILIZATION CRITERIA

INFRASTRUCTURE

1. PRIOR TO BEGINNING INFRASTRUCTURE CONSTRUCTION, THE OPERATOR(S) ARE REQUIRED TO SUBMIT AN UPDATED EROSION CONTROL DRAWING TO THE CITY OF ALBUQUERUE THAT IS SPECIFIC TO THE INFRASTRUCTURE PHASE OF CONSTRUCTION. REVISE OR AMEND THE SWPPP AND NOI(S) AS APPROPRIATE

SALES & VERTICAL CONSTRUCTION

- 1. THE MAINTENANCE OF BMPS ON THE PURCHASED PROPERTY AND RESPONSIBILITY TO COMPLY WITH THE 2022 CGP AND COA STORMWATER QUALITY REGULATIONS TRANSFER TO THE PURCHASING PARTY UPON COMPLETION OF THE SALE.
- 2. THE PURCHASING PARTY OF EACH COMMERCIAL LOT SHALL SUBMIT A SEPARATE EROSION CONTROL DRAWING AND NOI PER THE COA REQUIREMENTS. THE PURCHASING PARTY MUST HAVE AN APPROVED COA EROSION CONTROL PERMIT AND ACTIVE NOTICE OF INTENT BEFORE COMMENCING ANY EARTH DISTURBING ACTIVITIES.
- 3. THE PROPERTY OWNER MAY TERMINATE ITS PERMIT AUTHORIZATION AFTER INFRASTRUCTURE IS COMPLETE AND ALL INDIVIDUAL COMMERCIAL LOTS ARE SOLD AND SUCESSFULLY PERMITTED BY THE PURCHASING PARTY.





SWPPP Stormwater **Erosion Control**

Reclamation Seeding

www.e2rc.com | 505.867.4040

REVISION ITEM

NS, LLC -URNITURE EARTHWORK NOTES CONSTRUCTION SOLUTIONS IERICAN FU GUZMAN EMO AM

DESIGNED BY: K. FETTER, P.E. DRAWN BY: S. FETTER

SHEET: 2 - SWPPP

NOTES

GENERAL NOTES

THE NPDES COMPLIANCE SWPPP DRAWING AND ASSOCIATED DOCUMENTATION IS AND SHALL BE CONSIDERED A LIVING DOCUMENT ALLOWING FOR MODIFICATIONS AS SITE CONDITIONS CHANGE OR DICTATE.

ALL SITE FEATURES (EXISTING/PROPOSED GRADES, EXISTING CONSTRUCTION, FUTURE CONSTRUCTION, ETC.) SHOWN IS PER INFORMATION FROM OTHERS.

MINIMUM REQUIREMENTS TO FURTHER DEVELOP OR MODIFY THIS STORMWATER POLLUTION PREVENTION PLAN (SWPPP) DRAWING SHALL BE BASED ON THE CURRENT EDITION OF THE NEW MEXICO STATE HIGHWAY AND TRANSPORTATION DEPARTMENT (NMSHTD), NPDES LAW AND CITY OF ALBUQUERQUE ORDINANCE § 14-5-2-11.

ALL OPERATORS SHALL SUBMIT A NOTICE OF INTENT (NOI). THE NOI SHALL BE ACTIVE AND POSTED ON THE EPA'S WEBSITE PRIOR TO COMMENCING EARTH DISTURBING ACTIVITIES.

LOCATE TEMPORARY WASHOUT, ANCHORED TOILETS, CONSTRUCTION ENTRANCE AND PARKING, STAGING, REFUELING, TRASH CONTAINMENT AREA TO MINIMIZE SITE DISTURBANCE DURING CONSTRUCTION ACTIVITY.

THE OPERATOR IS REQUIRED TO REGULARLY PERFORM STREET SWEEPING AND CLEAN - UP MEASURES IN THE EVENT OF SEDIMENT TRACK - OUT.

THE FOLLOWING ARE STANDARD EROSION CONTROL REQUIREMENTS PER THE CITY OF ALBUQUERQUE STORMWATER QUALITY DEPARTMENT (JUNE 16, 2023):

ALL EROSION AND SEDIMENT CONTROL (ESC) WORK ON THESE PLANS, EXCEPT AS OTHERWISE STATED OR PROVIDED HEREON SHALL BE PERMITTED, CONSTRUCTED, INSPECTED, AND MAINTAINED IN ACCORDANCE WITH:

THE CITY ORDINANCE § 14-5-2-11, THE ESC ORDINANCE; THE EPA'S 2022 CONSTRUCTION GENERAL PERMIT (CGP); AND THE CITY OF ALBUQUERQUE CONSTRUCTION BMP MANUAL

ALL BEST MANAGEMENT PRACTICES (BMPS) MUST BE INSTALLED PRIOR TO BEGINNING ANY EARTH MOVING ACTIVITIES EXCEPT AS SPECIFIED HEREON IN THE PHASING PLAN. CONSTRUCTION OF EARTHEN BMPS SUCH AS SEDIMENT TRAPS, SEDIMENT BASINS, AND DIVERSION BERMS SHALL BE COMPLETED AND INSPECTED PRIOR TO ANY OTHER CONSTRUCTION OR EARTHWORK. SELF-INSPECTION IS REQUIRED AFTER INSTALLATION OF THE BMPS AND PRIOR TO BEGINNING CONSTRUCTION.

SEE SECTION 3.5 OF THE SWPPP NARRATIVE OR THE CONTRACTOR'S SCHEDULE FOR BMP SCHEDULING OR PHASING.

SELF-INSPECTIONS - IN ACCORDANCE WITH CITY ORDINANCE § 14-5-2-11(C)(1), AT A MINIMUM A ROUTINE SELF-INSPECTION IS REQUIRED TO REVIEW THE PROJECT FOR COMPLIANCE WITH THE CONSTRUCTION GENERAL PERMIT ONCE EVERY 14 DAYS AND AFTER ANY PRECIPITATION EVENT OF 1/4 INCH OR GREATER UNTIL THE SITE CONSTRUCTION HAS BEEN COMPLETED AND THE SITE DETERMINED AS STABILIZED BY THE CITY. REPORTS OF THESE INSPECTIONS SHALL BE KEPT BY THE PERSON OR ENTITY AUTHORIZED TO DIRECT THE CONSTRUCTION ACTIVITIES ON THE SITE AND MADE AVAILABLE UPON REQUEST.

CORRECTIVE ACTION REPORTS MUST BE KEPT BY THE PERSON OR ENTITY AUTHORIZED TO DIRECT THE CONSTRUCTION ACTIVITIES ON THE SITE AND MADE AVAILABLE UPON REQUEST.

FINAL STABILIZATION AND NOTICE OF TERMINATION (NOT) - IN ACCORDANCE WITH CITY ORDINANCE § 14-5-2-11(C)(1), SELF-INSPECTIONS MUST CONTINUE UNTIL THE SITE IS "DETERMINE AS STABILIZED BY THE CITY:. THE PROPERTY OWNER/OPERATOR IS RESPONSIBLE FOR DETERMINING WHEN THE "CONDITIONS FOR TERMINATION CGP COVERAGE" PER CGP PART 8.2 ARE SATISFIED AND THE FOR FILING THEIR NOT WITH THE EPA. EACH OPERATOR MAY TERMINATE GCP COVERAGE ONLY IF ONE OR MORE OF THE CONDITIONS IN PART 8.2.1, 8.2.2 OR 8.2.3 HAS OCCURRED. AFTER FILING THE NOT WITH THE EPA, THE PROPERTY OWNER IS RESPONSIBLE FOR REQUESTING A DETERMINATION OF STABILIZATION FROM THE CITY.

WHEN DOING WORK IN THE CITY RIGHT-OF-WAY (E.G., SIDEWALK, DRIVE PADS, UTILITIES, ETC.) PREVENT SEDIMENT FROM ENTERING THE STREET. IF SEDIMENT IS PRESENT IN THE STREET, THE STREET SHOULD BE SWEPT DAILY OR PRIOR TO A RAIN EVENT OR CONTRACTOR INDUCED WATER EVENT (E.G. CURB CUT OR WATER TEST).

WHEN CUTTING THE STREET FOR UTILITIES, THE SEDIMENT SHALL BE PLACED ON THE UPHILL SIDE OF THE STREET CUT AND THE AREA SWEPT AFTER WORK IS COMPLETE. A WATTLE OR MULCH SOCK MAY BE PLACED AT THE TOE OF THE EXCAVATED DIRT PILE IF SITE CONSTRAINTS DO NOT ALLOW PLACING THE EXCAVATED DIRT ON THE UPHILL SIDE OF THE STREET CUT.


EROSION AND SEDIMENT CONTROL (ESC) PLANS MUST SHOW LONGITUDINAL STREET SLOPE AND STREET NAMES. ON STREETS WHERE THE LONGITUDINAL SLOPE IS STEEPER THAN 2.5%, WATTLES OR MULCH SOCKS OR J-HOOKED SILT FENCE SHALL BE SHOWN IN THE FRONT YARD SWALE OR ON THE SIDE OF THE STREET.





SWPPP
Stormwater
Erosion Control
Reclamation

www.e2rc.com | 505.867.4040




GUZMAN CONSTRUCTION SOLUTIONS, LLC AMERICAN FURNITURE DEMOLITION & EARTHWORK SWPPP NOTES


DESIGNED BY:
K. FETTER, P.E.
DRAWN BY:
S. FETTER

SHEET:

3 - GENERAL NOTES




2' FOR DRAWING ONLY. 8' MAX SPACING BETWEEN STAKES



SECURE WATTLE WITH 18-24" STAKES EVERY 3-4' AND STAKES ON EACH END OF THE WATTLE.

DRIVE STAKES PERPENDICULAR TO THE SLOPE FACE AND THROUGH THE MIDDLE OF THE WATTLE LEAVING AT LEAST 2-3" OF THE STAKE ABOVE THE WATTLE.

VERTICAL SPACING DEPENDENT ON SLOPE GRADIENT.



SILT FENCE

NTS

SILT FENCE IS TO BE PLACED PERPENDICULAR TO THE SLOPE OF THE SITE.

DIG A 4"X4" MINIMUM TRENCH UPSTREAM OF THE SILT FENCE. DRIVE STAKES AT LEAST 1' DEEP ON THE DOWNSTREAM EDGE.

RUN THE SILT FENCE ON THE INSIDE OF THE STAKES AND SECURE WITH HOG RINGS, WIRE, ZIP TIES OR STAPLES.

IF ONE CONTINUOUS PIECE OF FABRIC IS NOT AVAILABLE, OVERLAP THE FABRIC AT LEAST THE WIDTH OF THE STAKE AND SECURE WITH HOG RINGS, WIRE, ZIP TIES OR STAPLES.

COVER TRENCH WITH BACKFILLED COMPACTED SOIL, GRAVEL OR ROCK.



SWPPP
Stormwater
Erosion Control
Reclamation
Seeding

www.e2rc.com | 505.867.4040


DATE REVISION ITEM

GUZMAN CONSTRUCTION SOLUTIONS, LLC AMERICAN FURNITURE DEMOLITION & EARTHWORK

DESIGNED BY:
K. FETTER, P.E.
DRAWN BY:
S. FETTER

SHEET:

4




SPOILS PILE PROTECTION

PLACE WATTLES IN FUTURE LOCATIONS OF SPOILS STOCKPILES PRIOR TO CONSTRUCTION.

PLACE WATTLES CONTINOUSLY ALONG THE EXTENT OF THE SPOILS STOCKPILE.

ANCHOR THE WATTLES USING A MINIMUM OF 1" X 2" X 18" WOODEN STAKES OR SAND BAGS.


ONCE/IF THE SPOILS STOCKPILE IS DEPLETED OR MOVED, REMOVE THE WATTLES AND REUSE THEM IN THE NEXT LOCATION.



PLACE CHECK DAMS AT REGULARLY SPACED INTERVALS ALONG SWALE OR DRAINAGE DITCH.

HEIGHTS SHOULD ALLOW FOR POOLS TO DEVELOP UPSTREAM OF EACH CHECK DAM.

IF MULTIPLE DAMS ARE USED, THE TOP OF THE LOWER DAM SHOULD BE THE SAME HEIGHT AS THE ELEVATION AS THE TOE OF THE UPPER DAM.




RUNDOWN DETAIL

8' MAX SPACING BETWEEN STAKES

PLACE WATTLES AT THE TOE OF SLOPE. THE RIP RAP OR CONCRETE RUNDOWN SHOULD ABUT THE WATTLE.

ANCHOR THE WATTLES WITH WOODEN STAKES, DRIVE THE STAKE A MINIMUM OF 12" INTO THE MIDDLE OF THE WATTLE AND SOIL UNDERNEATH.

2-3" OF THE WOODEN STAKE SHOULD BE PRESENT ABOVE THE WATTLE.




OPEN TRENCH SPOILS PILE PROTECTION

PLACE WATTLES CONTINUOUSLY ALONG THE EXTENT OF THE UTILITY TRENCH AND FUTURE LOCATION OF THE SPOILS STOCKPILE PRIOR TO EXCAVATION OF THE UTILITY.

WATTLES ARE TO REMAIN ANCHORED IN PLACE UNTIL THE UTILITY TRENCH IS BACKFILLED.

ANCHOR THE WATTLES USING A MINIMUM 1"X2"X18" WOODEN STAKE OR SANDBAGS.

ONCE THE TRANCH IS BACKFILLED, WATTLES MAY BE REMOVED AND REUSED IN THE NEXT SECTION OF EXCAVATION PROVIDED THEY ARE IN GOOD CONDITION.



CONSTRUCT AN EARTHEN BERM DOWN HILL OF THE AREA TO BE CONTROLLED.

BERM SHOULD BE A MINIMUM 12" HIGH AND 12" WIDE.

USE EQUIPMENT TO COMPACT EARTHEN BERM BY ROLLING OVER BERM TO MINIMIZE SPREAD.





www.e2rc.com | 505.867.4040

SWPPP Stormwater **Erosion Control** Reclamation

Seeding


NTS


SHEET:

REVISION ITEM

SOLUTIONS, LLC MERICAN FURNITURE OLITION & EARTHWORK CONSTRUCTION GUZMAN

DESIGNED BY: K. FETTER, P.E. DRAWN BY: S. FETTER






THE MAT SHOULD EXTEND A MINIMUM OF 1" PAST ALL EDGES OF THE INLET. PLACE MAT AGAINST THE CURB INLET.

PLACE WATTLES ON TOP OF THE MAT CLOSEST TO THE INLET OPENING AND CURB.

THE MAXIMUM HEIGHT OF THE PROTECTIVE BARRIER MUST BE LOWER THAN THE TOP OF THE CURB OPENING. THIS ALLOWS OVERFLOW INTO THE INLET DURING LARGE PRECIPITATION EVENTS.

ANCHOR THE BARRIER NETTING OVER THE CURB WITH WOODEN STAKES IF ABLE. IF UNABLE TO DO THAT ANCHOR THE WATTLE WITH SAND BAGS ON EACH END.



CUTBACK CURB

NTS

CUTBACK CURBS SHOULD TYPICALLY BE INSTALLED AT THE SITE ENTRANCE WHEN ACCESS IS NEEDED.

SOIL SHOULD BE CUT BACK FROM BEHIND THE CURB, SIDEWALK OR ROADWAY A MINIMUM 2" DOWN FROM THE TOP OF THE HARDSCAPE.

BRING THE SOIL BACK >10 FEET FT FROM THE HARDSCAPE TO FORM THE SEDIMENT TRAP.

THE LOWEST POINT OF THE SEDIMENT POND SHALL BE AT LEAST 10 INCHES.

IF THE HOUSE PAD HAS BEEN STABILIZED, THE DEPTH OF THE SEDIMENT POND MAY BE REDUCED TO 4 INCHES.

THE DEPTH AND LENGTH OF THE EXCAVATED AREA CAN BE INCREASED IF MORE STORAGE IS NEEDED.

INSPECT BMPs PRIOR TO FORCAST PRCIPITATION, DAILY DURING PRECIPITATION EVENTS, AFTER PRECIPITATION EVENTS AND THROUGH THE LIFE OF THE PROJECT.

MAINTAIN PROPER DEPTH AND LENGTH OF THE CUTBACK FOR THE DURATION OF THE PROJECT.

KEEP CUTBACK AREA CLEAN AND FREE OF TRASH AND DEBRIS.



REVISION ITEM

SWPPP
Stormwa
Erosion
Reclama
Seeding

Stormwater
Erosion Control
Reclamation

SHEET:

www.e2rc.com | 505.867.4040


6


DESIGNED BY:

DRAWN BY:

S. FETTER

K. FETTER, P.E.





CONCRETE WASHOUT

LOCATE WASHOUT AT LEAST 50 FT FROM STORMDRAINS, OPEN DITCHES, WATER BODIES OR PROJECT PERIMETER. A SIGN SHOULD BE INSTALLED ADJACENTLY TO THE WASHOUT.

WASH OUT WASTE INTO THE WASHOUT WHERE THE CONCRETE CAN SET, BE BROKEN UP AND DISPOSED OF CORRECTLY.

DO NOT CREATE RUNOFF BY DRAINING WATER TO BERMED AREA OR BY COLLECTING THE WATER WASTE WHEN WASHING CONCRETE TO REMOVE PARTICLES AND EXPOSE THE AGGREGATE.


DO NOT WASH SWEEPINGS FROM EXPOSED AGGREGATE CONCRETE INTO THE STREET, STORMDRAIN SYSTEMS OR OFF THE PROJECT SITE.



PORTABLE TOILET STAKING

PLACE THE PORTABLE TOILET ON LEVEL GROUND. A FLAT PAVED SURFACE IS BEST IF AVAILABLE.

DRIVE THE STAKES OVER THE SKIDS OF THE PROTABLE TOILET, AROUND ALL SIDES.




CRUSHED AGGREGATE GREATER THAN 75 MM (3 IN.) BUT SMALLER THAN 150 MM (6 IN.)

FILTER FABRIC

ORIGINAL

300 MM (12 IN), UNLESS OTHERWISE SPECIFIED BY A SOILS ENGINEER



STABILIZED CONSTRUCTION **ENTRANCE**

CONSTRUCT THE ENTRANCE ON A LEVEL SURFACE WHERE AN UNPAVED ROAD MEETS A PAVED ROAD. TYPICALLY AT PROJECTS ACCESS AREA.

GRADE THE ENTRANCE TOWARD THE CONSTRUCTION SITE TO PREVENT RUNOFF.

INSPECT THE ENTRANCE TO KEEP TRASH AND DEBRIS OUT OF THE WAY.

AFTER PRECIPTATION EVENTS, INSPECT THE ENTRANCE FOR ANY REPAIRS THAT MAY BE NEEDED.

NPDES POSTING BOARD

NTS

NPDES Permit must

be positioned at the most active part of

the project where it

can be viewed by

project entrance)

the public (e.g.



POST - CONSTRUCTION FLOW PRE - CONSTRUCTION FLOW

SILT FENCE

WATTLE OR SOCK SPOILS PILE PROTECTION

EARTHEN BERM INLET PROTECTION

NATURAL BUFFER

PARKING AND STAGING AREA

CONCRETE WASHOUT

STABILIZED CONSTRUCTION **ENTRANCE**

VEGETATIVE STABILIZATION

ENDANGERED/THREATENED SPECIES

CHECK DAM

CHEMICAL STORAGE

TEMP TOILET

LOCATION FOR PUBLIC NOTIFICATION OF NPDES PROJECT BOUNDRY DISTURBED AREA PROJECT AND DISTURBED

BOUNDRY CULVERT BLANKET

CUTBACK CURB

PARKING AND STAGING AREA. CHEMICAL STORAGE AND CONCRETE WASHOUT IN APPROXIMATE LOCATION. TOGETHER IF MOVED. AREAS CAN BE MOVED AFTER START OF

DRAWING KEY

SWPPP Stormwater **Erosion Control**

Reclamation SHEET:

www.e2rc.com | 505.867.4040

DESIGNED BY: K. FETTER, P.E. DRAWN BY: S. FETTER

SOLUTIONS, LLC MERICAN FURNITURE OLITION & EARTHWORK

CONSTRUCTION

GUZMAN

REVISION ITEM

