

Lovelace R.R.I. Increase in Flow	
Undeveloped Flow (Q)	0.46 (CFS)
Developed Flow (Q)	0.62 (CFS)
Developed - Undeveloped =	0.16 (CFS)