


TYPICAL UTILITY CUT DETAIL


NOT TO SCALE

NOTE:
AN ALTERNATIVE TEMPORARY EROSION AND SEDIMENT CONTROL OPTION IS TO PLACE STOCK PILE ON UPSTREAM SIDE OF UTILITY CUT. CONTRACTOR TO APPLY FOR 6NOI WITH THE EPA PRIOR TO BEGINNING ANY SAWCUTTING OR UTILITY TRENCHING.




TYPICAL WATTLE DETAIL

NOT TO SCALE




COMPOST SOCK CONNECTION/ATTACHMENT DETAIL



BEDDING DETAIL

NOTES:


1. row with ends tightly abutting the adjacent bales.
2. Each bale shall be embedded in the soil a minimum of 4", and placed so that bindings are horizontal.
3. Bales shall be securely anchored in place by either two stakes or re-bars driven through the bale. The first stake in each bale shall be driven toward the previously laid bale at an angle to force the bales together. Stakes shall be driven flush with the bale.
4. Inspection shall be frequent and repair replacement shall be made promptly as needed.
5. Bales shall be removed when they have served their usefulness so as not to block or impede storm flow or drainage.




ANCHORING DETAIL

TYPICAL STRAW BAIL BARRIER

NOT TO SCALE



ELEVATION




FABRIC ANCHOR DETAIL

TYPICAL SILT FENCE DETAIL

NOT TO SCALE

NOTES:

1. Temporary silt fence shall be installed prior to any grading work in the area to be protected. Fence shall be maintained throughout the construction period and removed in conjunction with the final grading and site stabilization.
2. Filter fabric shall meet the requirements of material specification 592 Geotextile Table 1 or 2, Class I with equivalent opening size of at least 30 for nonwoven and 50 for woven.
3. Fence posts shall be either wood post with a minimum cross-sectional area of 1.5" X 1.5" or a standard steel post.
4. When splices are necessary make splice at post according to splice detail. Place the end post of the second fence inside the end post of the first fence. Rotate both posts together at least 180 degrees to create a tight seal with the fabric material. Cut the fabric near the bottom of the posts to accommodate the 6 inch flap. Then drive both posts and bury the flap. Compact backfill well.



SPlice DETAIL-PLAN VIEW

